OC 4

The compact pressure washer with lithium-ion battery and water tank for cleaning on the go without a power supply or water connection – optimum cleaning performance for many applications.



DESIGN AWARD 2025

Order no. **1.599-350.0**

- Pressure washer with integrated water tank (8 l), low pressure (7 bar)
- Battery-powered, max. 22 min runtime, trigger gun with locking, compact design
- Flat jet nozzle, battery charger

Technical data

EAN code		4066529103741
Pressure range		Low pressure
Flow rate	**l/min**	max. 2
Battery powered device		1
Battery type		Lithium-ion battery
Battery run time	**min**	max. 22
Battery charge time	**h**	3.5
Colour		grey
Weight without accessories	**kg**	3.1
Weight incl. packaging	**kg**	4.3
Dimensions (L × W × H)	**mm**	296 × 291 × 240

Scope of supply

Battery charger: 5 V / 2 A USB-C charging cable + adapter (1 piece each)

Flat jet nozzle

Equipment

Water suction

Water tank volume: 8 l

Hose length: 2.8 m

Hose type: Low-pressure spiral hose

Integrated water filter

Pressure trigger gun: Low-pressure trigger gun

Device filter

OC 4, 1.599-350.0, 2026-06-14





Cleaning on the move

- The 8-litre water tank and integrated rechargeable battery makes cleaning on the go easy – even without a water supply or power connection.
- The tank can be removed for filling from a tap or other water sources and, thanks to the leak-proof cap, it can be transported without worry, e.g. in the car boot.
- Flexible for use in many different cleaning tasks, e.g. for bicycles, garden and camping equipment, dogs or prams.



Integrated lithium-ion battery

- One battery charge gives a runtime of up to 22 minutes, long enough to thoroughly clean several dirty items, such as bicycles or garden furniture.
- The LED light provides information about the current charge status of the battery.
- The USB type C charging socket enables flexible charging even when out and about, e.g. in the car or from a powerbank.




Sophisticated storage concept

- Takes up minimal space in transit and in storage – the device, hose and trigger gun can all be packed away inside the empty water tank.
- The accessory bags, available as optional extras, can also be stored inside the tank.
- Transport with ease and save space in storage.

OC 4, 1.599-350.0, 2026-06-14

SUSTAINABILITY INFORMATION FROM OC 4
1.599-350.0



Sustainability features		
Sustainable packaging	100% plastic-free packaging	Related to packaging inside box

KÄRCHER

ACCESSORIES FOR OC 4
1.599-350.0


1


2


3


4


5


6


7


8


9


10


11


12


13


14

		Order no.	Description	
MOBILE OUTDOOR CLEANER				
Adventure accessory bag	1	2.644-510.0	The ideal addition to Kärcher low-pressure washers: the Adventure accessory bag can be used to clean outdoor equipment effortlessly anywhere thanks to its accessories designed to work perfectly with the cleaner.	☐
Bike accessory bag	2	2.644-511.0	The ideal addition to a Kärcher low-pressure washer: the Bike accessory bag contains practical accessories that have been specially developed for cleaning bicycles.	☐
Pet accessory bag	3	2.644-512.0	The ideal addition to Kärcher low-pressure washers: the Pet accessory bag contains practical accessories that have been specially developed for gentle cleaning of dogs.	☐
Universal brush	4	2.643-870.0	The universal brush for optimal brush cleaning. It is mounted onto the trigger gun of the pressure washer, removes stubborn dirt and protects delicate components.	☐
Pet cleaning brush	5	2.643-874.0	For thoroughly brushing animal fur: the fur-cleaning brush removes even stubborn dirt from fur.	☐
Pet wash brush	6	2.644-421.0	The wash brush for gently cleaning and grooming pets, particularly dogs. Simply fit to the OC 3 pressure washer for effective cleaning. Clean fur in just a few simple steps!	☐
Scrubbing brush	7	2.644-423.0	The versatile scrubbing brush for mobile cleaning removes stubborn dirt quickly and thoroughly. Can be fitted directly on the trigger gun of the pressure washer.	☐
Detail brush	8	2.644-420.0	The small and powerful fine-detail brush for mobile cleaning guarantees the targeted removal of dirt in hard-to-reach places. Can be fitted directly on the trigger gun of the pressure washer.	☐
Low-pressure Multi Jet	9	2.644-499.0	Versatile 4-in-1 multi-nozzle for the OC 3 and OC 4 mobile pressure washers with spot, flat, mist and stream jet for a range of different applications. Easy to adjust simply by turning the nozzle head.	☐
Cone jet nozzle	10	2.643-875.0	Clean your pet quickly and simply with the conical jet nozzle. It can be mounted onto the trigger gun of the pressure washer and produces a gentle shower stream.	☐
Detail nozzle	11	2.644-125.0	The detail nozzle cleans details, narrow crevices and stubborn dirt. It is adapted to the pressure washer's spray gun and produces a powerful thin jet.	☐
Splash guard	12	2.644-169.0	The transparent splash guard for the Mobile Outdoor Cleaner protects users and their surroundings from spray water and is easy to store away by folding it together (in four steps).	☐
Foam jet	13	2.644-419.0	Handy foam jet for dispensing Home & Garden detergents for extra thorough cleaning. Fitted directly on the trigger gun of the pressure washer.	☐
Suction hose	14	2.643-871.0	The suction hose for mobile cleaning is mounted onto the pressure washer and enables the use of alternative water sources like wells and water canisters.	☐

☐ Available accessories.

ACCESSORIES FOR OC 4
1.599-350.0



15



16

		Order no.	Description	
MOBILE OUTDOOR CLEANER				
Microfibre cloth	15	2.643-872.0	With the high-quality fleece microfibre cloth, the cleaned objects can be dried before they are stored.	☐
Pet towel	16	2.643-873.0	Special microfibre cloth for drying off dogs. Absorbs a lot of water and eliminates unpleasant odours.	☐

☐ Available accessories.